Model 276986 Extra Large Talking Calculator

INSTRUCTION OF YL-3025 LCD TALKING CALCULATOR

USER Information

This calculator runs on 2 AAA batteries.

Calculator Function

Press "CE" or "AC" key to enter calculator mode.

Press "REP" key to repeat the displayed value. Press

"U/D" key to express Value or Digits of display.

Press "MR" key to show memory contents. Me clears, M+ adds to and **M**-subtracts from memory. Use M+ or M- instead of = to enter result directly to memory.

Volume- There is three levels for volume control. The volume can be in off/mute position, soft or loud. There is also an option to use the calculator with headphones, in which case only the person using the headphones will hear the calculator talking. The headphone jack can be found in the left side of the calculator.